




IN230300013V02\_US

**820-251V80**



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

# ASSEMBLY & INSTRUCTION MANUAL

WHEN USING ELECTRICAL APPLIANCES, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK AND INJURY TO PERSON, INCLUDING THE FOLLOWING:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use grip handle when provided.
- Keep combustible materials such as drapes, furniture, pillows, bedding, papers, clothes, and curtains at least three (3) feet (0.9m) from the front of heater and keep them at least 1 foot (0.3m) the sides and rear of the heater.
- Extreme caution is necessary when heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not use any heater with a damaged cord or plug or after the heater malfunctions or has been dropped or damaged in any manner. Return heater to manufacturer for examination, electrical or mechanical adjustment, or repair.
- Do not use outdoors.
- This heater is not to be used in bathrooms, laundry areas or other similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over.
- To disconnect heater, turn control to OFF then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause electric shock or fire or damage the heater.
- To prevent possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored.
- Use this heater only as directed in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- If the heater will not operate: See specific instructions in Safety Feature explained in this manual.

### **CLEANING/ MAINTENANCE INSTRUCTIONS:**

#### **During Season Care:**

- Before cleaning, be sure to turn off and unplug the heater.
- Carefully wipe the unit with a soft, damp cloth. Please be very cautious near the motor and heating elements.
- Do not immerse the heater in water.
- Never use gasoline, benzene or thinner. This will damage the surface of the heater.
- After cleaning, be sure to completely dry the unit with a cloth or towel.


#### **After Season Care:**

- Store heater in a cool and dry location with power cord properly secured.
- Please store the unit in its original carton or suitable container.

### **PRE - OPERATING INSTRUCTIONS:**

- Carefully remove your heater from the box (please save the carton for off-season storage)
- Make sure the unit is in the OFF position before plugging the heater into the outlet.
- Place heater on a firm level surface.

## OPERATING INSTRUCTIONS:



- Before inserting the plug into an electrical outlet, make sure that the electrical supply in your area matches that on the rating label on the unit.
  - When plugged in, turn on the Main power switch at the back of the unit.
  - When in Standby mode, only the switch (⏻) on the control panel will respond to your touch, and the LED display shows the room temperature. Press (⏻) to access the rest of the control panel or remote control.
- a) Low Power: 750W (Press “☀️” to switch it)
- b) High Power: 1500W (Press “☀️” to switch it)
- c) TIMER: Press “🕒” button repeatedly to set a period after which the heater will turn itself off (From 0 hour – 8 hours)
- d) + , - : adjust room temperature only by remote control.
- Temperature setting from 50-95 °F. “+” to increase the desired temperature and “-“ to decrease the desired temperature. (On Remote control only)
- e) Osc: Press “⏮️” to activate oscillation. Press it again to cancel.
- f) Press (⏻) to turn off the heater, the unit will keep working 30 seconds of cool air after turn off it . this design can protect item use longer.

**Warning: The heater will remain hot for some time after it is turned off; handle with care.**





## REMOTE CONTROL

The remote control uses on button cell battery, type CR2025(3V). To remove the battery carriage use your thumb to squeeze the release tab to the right and then pull the carriage out. Place the battery into the carriage and slide the carriage back into the remote. See Fig.1. We recommend the use of a Lithium-ion battery for longer use.

**NOTE:** Follow battery disposal instruction on battery packaging, or contact your local safety council for safely disposal of batteries.

Before using the remote control, you must remove the insulating film as shown in the figure below.

1. All functions performed with remote control work identically to the heater control panel.
2. Aim the remote control at the heater control panel to operate the heater.



**Installation Method of Remote Controller Battery**

negative

positive

1. The battery cover can be removed by gently pulling it down.
2. Put the battery into the battery box. (Note the positive and negative direction of the battery)
3. Put the battery cover into the original outlet and fasten it completely.

D 5HP RYH OG P LP HGLDMMO HF\FOI U LS RVH IR XHG EMMUHV EFRUGLQ RVREDO UHXOMRQV OG HHHS ZDA URP FKLOUHQ '2 127 QSRVH IR EMMUHV Q RRVHKRQ WDVK BQELCHUDM

E (YHQ VHG EMMUHV IA EXVH NYHUH QXU RU HOK

F EDO BFDO RS/RQ RQARO HEMU RU UNDA HQVQRUP DMRQ

G 'RQHFKDUJHDEOI EMMUHV IH RVR VIE HFKDUJHG

H 'R RVRUFH HFKDUJH HFKDUJH QDVHP EOI KDW EBYH P DQXIDFVXUHV SHFLHG WIP SHUDXUH DMQ BQELCHUDM 'RQJ R IA HVXONQ QXU QH RVHQMQJ HONDUH RU [SRVLRQ HVXONQ Q KHP LFDO XEQV

I (QXUH KIV EMMUHV IH QMDXG RRUHFVO EFRUGLQ RV SDUW DQG

J 'R RV UP RG OG KZ EMMUHV QHUHQW URGV IA SHV IR EMMUHV XFK D DODQGH BUERQ IQF B HEKDUJHDEOI EMMUHV

K 5HP RYH OG P LP HGLDMMO HF\FOI U LS RVH IR EMMUHV URP HXLSP HQW RQ VAG RU DQ [HMQGHG ISURG IRLVH EFRUGLQ RVREDOHUXOMRQV

L \$QDA V RRP SOMMO VFXUH KIV EMMU RRP SDUW HQW I, KM EMMU RRP SDUW HQW RGV RQ FORVH HFXUHO VRS XQJ KM SRGXFW HP RYH KIV EMMUHV OG HHHS KMP ZDA URP FKLOUHQ



