


Soozier

IN220800291V01_US_CA

A62-023



FR: INSTRUCTIONS D'ASSEMBLAGE

EN: ASSEMBLY INSTRUCTION

FR: IMPORTANT : A LIRE ATTENTIVEMENT ET À CONSERVER POUR CONSULTATION ULTÉRIEURE.

EN: IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

EN

Dear customer,

Thank you for purchasing this product. So that your appliance serves you well, please read all the instructions in this user's manual. If you have any questions, please contact our customer care center.

FR












Cher client,


Nous vous remercions d'avoir acheté ce produit. Afin que vous puissiez profiter pleinement de votre appareil, veuillez lire toutes les instructions de ce manuel d'utilisation. Si vous avez la moindre question, veuillez contacter notre centre d'assistance à la clientèle.


EN_Our contact details are below:

FR_Nos coordonnées sont les suivantes:

Country	 Phone	 Email
US	001-877-644-9366	customerservice@aosom.com
CA	416-792-6088	customerservice@aosom.ca

 ① x 4	 ② x 2	 ③ x 2	 ④ x 1
 ⑤ x 1	 ⑥ x 2	 ⑦ x 1	 ⑧ x 1
 ⑨ x 2	 ⑩ x 2	 ⑪ x 2	 ⑫ x 2
 A x 1	 B x 4	 C x 1	 D x 18
	 E x 11	 F x 8	 G x 1





EN: Tips: Tie the PE rope in a knot and wrape the rope according to net mesh.

FR: Conseils : Attachez la corde PE dans un nœud et enveloppez la corde selon la maille du filet.

EN: Tips: Fasten the shooting tatget on the frame by the elastic ropes.

FR: Conseils : Attachez la cible de tir sur le cadre par les cordes élastiques.

