




















IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


Tools Recommended




ASSEMBLY & INSTRUCTION MANUAL





 <p>A x29</p>	 <p>B x29</p>	 <p>C x12</p>	 <p>D x 4 M5*45</p>
 <p>E x 1 M4*30</p>	 <p>F x14 M3*12</p>	 <p>G x12 M3.5*12</p>	 <p>H x 1</p>
 <p>I x 1</p>	 <p>J x 1 M4*16</p>	 <p>K x 2</p>	 <p>L x 1</p>
 <p>M x 1</p>	 <p>N x 1 M4*14</p>	 <p>O x 4</p>	 <p>P x10</p>





















- | | | |
|--|--|--|
| <p>B</p>  <p>x3</p> | <p>C</p>  <p>x2</p> | <p>P</p>  <p>x2</p> |
|--|--|--|










- | |
|---|
| <p>B</p>  <p>x4</p> |
|---|









US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it