



INfja001V02_UK

370-198



CHILDREN TRICYCLE

*Suitable for children of 1-5 years old.

*Max weight: 25 kg.



Please according to the actual one in the box, the picture is for reference.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY INSTRUCTION



WARNING:

1. CHOKING HAZARD—Small parts.
2. Only allowed for adults to install, keep children away.
3. To be used under the direct supervision of an adult.
4. Just only allow one child to use.
5. Please use on a flat and clean surface. Never use near steps, sloped driveways, hills roadways, alleys, swimming pool areas, road, on grass or wet surfaces or other bodies of water.
6. Before driving toy car each time, adult should inspect screws of every parts, please tighten the screw cap if any looseness. secure all fasteners before every ride.
7. Always wear shoes and suitable protective equipment. always wear a local standard approved helmet while riding, with the chinstrap securely fastened.
8. Do not ride the product at dusk, at night or at times of limited visibility.
9. Always comply with local laws and regulations.


MAINTENANCE & CARE

- A. Keep all instructions and parts relating to this product for future reference.
- B. Regularly check for damage and that all screws are securely tightened.
- C. Check that the seat is securely fastened.
- D. Lubricate the chain as often as required.
- E. Regularly check tyre pressures.

Annotate:


When we improve the product, tricycle structure and appearance are subject to change without any notice. This manual is adapt to tricycle series, pictures for reference only, subject to our available products.

SPARE PARTS




<p>A</p>	<p>B</p>	<p>C</p>	<p>D</p>	<p>E</p>	<p>F</p>
<p>Frame x1</p>	<p>Front basket x1</p>	<p>Back wheel x2</p>	<p>Back Footrest x1</p>	<p>Front wheel x1</p>	<p>Canopy x1</p>
<p>G</p>	<p>H</p>	<p>I</p>	<p>J</p>	<p>K</p>	
<p>Push Rod x1</p>	<p>Headrest x1</p>	<p>Back basket x1</p>	<p>Handlebar x1</p>	<p>Brake pedal x2</p>	


Installation Steps




1. Open the back wheel frame
Open: Open the back wheel frame in the direction of the arrow as shown in the Picture 1.
Fold: Press the button under the frame to fold the back wheel frame.



2. Back wheels Installation
Install the brake pedal into the transverse pipe of the rear wheel frame, and then insert the rear wheel into the corresponding hole on the brake pedal to complete the rear wheel installation (pay attention to distinguish the left and right when install the brake pedal).




3. Footrest Installation
Open: as shown in Picture 3, pull the pull ring to turn over the footrest, and left and right pedal can be opened to use.
Close: Pull the pull ring to turn over the footrest, then fold the left and right pedal.




4. Back basket Installation
Put the back basket and footrest on the frame along the dotted line as shown in Picture 4, align the basket hole with the corresponding hole on the frame, please noted that must install back basket first.



5. Backrest Adjustment
As shown in Picture 5, hold the buttons on both sides of the backrest to adjust the angle of the backrest.




6. Front wheels/Front basket/Handlebar Installation
Insert the front wheel, front basket and handlebar according to the dashed line shown in Picture 6 in turn.
When inserting the front wheel, the arrow position on the fender should be forward, and the handlebar button should be installed forward. Pinch the button and insert it. After the installation, please check all the parts, the correct position is impossible to disengage.
If necessary, press the front button of the handlebar to remove the above three parts.




7. Armrest Installation
Press the button on the left and right to remove armrest, then you can put the baby into the seat, wear the seat belt, and then install the armrest.

Installation Steps



8. Installation of canopy support and headrest
As shown in picture 8, the canopy support is buckled to the back of the backrest, attache it on the round buckles, and then pulled down the canopy support to buckle in place; After the canopy support is installed, insert the headrest into the back of the backrest along the dotted line.




9. Canopy Installation:
Open the canopy as shown in PICTURE 9 and PICTURE 10 .




10. Push rod installation
Insert the push rod into the corresponding hole on the frame, as shown in Picture 11 .

Direction For Use




1. Unfolded the Footrest Pedal
There is a Footrest Pedal under frame 1. You can Unfolded the Footrest Pedal when your baby sit on the tricycle.


2. Backrest adjustment
As shown in Picture 12, hold the buttons on both sides of the backrest to adjust the angle of the backrest.



3. Seat rotation adjustment
Loose the screw under the frame to turn around the seat. (PICTURE 13)



4. Unfolded/Folded the sitting pedal
There is a sitting pedal under the frame, hold the circular plastic ring on the tube and pulling it down, the sitting pedal can be folded and Unfolded.



5. Lock the front wheel
Turn the red switch on the front wheel clockwise, and the front wheel is locked. Turn the red button counterclockwise to unlock