




IN221200312V01\_UK\_DE

001-014V00\_001-014V01\_001-014V02

EN



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

# ASSEMBLY INSTRUCTION

**Dear customer,**

Thank you for purchasing this product. So that your appliance serves you well, please read all the instructions in this user's manual. If you have any questions, please contact our customer care center.

**Our contact details are below:**

Country	 Phone	 Email
UK	0044-800-240-4004	enquiries@mhstar.co.uk

**IMPORTER ADDRESS:**

MH STAR UK LTD  
Unit 27, Perivale Park,  
Horsenden lane South  
Perivale, UB6 7RH

MADE IN CHINA

Format: 1.1

View angle: 120 °

Size: 80 inches 16:9

Projection area: 177cm×100cm

Overall size: 210cm ×172 cm×42cm


Operating temperature: -20°C~60°C

Weight: 2.6Kg

Due to improvements, the product you purchased may not be the same as the description in this manual. We apologise for any inconvenience!

- Features:**
1. Made from polyester fabric, it ensures the screen is flat when tightened to the frame.
  2. The frame is made of aluminium alloy.
  3. Fabric is anti-crease and washable.
  4. Users can assemble the product themselves.
  5. Nylon rope, stake and water bags keep the product stable outdoors. Only use when it is not windy outside.


### Parts




Pole A × 4




Pole B × 3



Pole C × 2



Corner connector × 2



Hanger × 8



Water bag × 2




Stake × 5



Nylon rope × 2 (About 8M)








Screen × 1




Storage bag × 1

# ASSEMBLING PARTS






Outdoor use



Note: Do not use in windy conditions – it could cause injury or damage the product.

Fill the bag with water – place it in the position shown above. When used in light wind, add the nylon rope, stake and water bag – keeping it secure.



WICHTIG - BITTE HEBEN SIE DIESE ANLEITUNG FÜR  
EINE SPÄTERE BEZUGNAHME AUF: SORGFÄLTIG DURCHLESEN

## MONTAGEANLEITUNG

**Sehr geehrter Kunde,**

Vielen Dank, dass Sie dieses Produkt erworben haben. Damit Ihr Gerät Ihnen gute Dienste leistet, lesen Sie bitte alle Hinweise in diesem Benutzerhandbuch. Wenn Sie Fragen haben, wenden Sie sich bitte an unser Kundendienstzentrum.

**Unsere Kontaktdaten stehen unten:**

Country	 Phone	 Email
DE	0049-0(40)-88307530	service@aosom.de

**ADRESSE DES IMPORTEURE:**

MH Handel GmbH  
Wendenstraße 309  
D-20537 Hamburg  
Germany

IN CHINA HERGESTELLT

Format: 1.1  
 Betrachtungswinkel: 120°  
 Größe: 80 Zoll 16:9  
 Projektionsfläche: 177 cm x 100 cm  
 Gesamtgröße: 210 cm x 172 cm x 42 cm  
 Betriebstemperatur: -20 °C bis 60 °C  
 Gewicht: 2,6 kg

Aufgrund von Verbesserungen kann es sein, dass das von Ihnen gekaufte Produkt nicht mit der Beschreibung in dieser Anleitung übereinstimmt.

Wir entschuldigen uns für eventuelle Unannehmlichkeiten!


### Merkmale:

1. Sie besteht aus Polyestergewebe und bewirkt, dass die Leinwand flach ist, wenn sie am Rahmen befestigt wird.
2. Der Rahmen ist aus einer Aluminiumlegierung gefertigt.
3. Das Gewebe ist knitterfrei und waschbar.
4. Der Benutzer kann das Produkt selbst aufstellen.
5. Nylonseil, Heringe und Wassersäcke halten das Produkt im Außenbereich stabil. Nur verwenden, wenn es draußen nicht windig ist.


### Teile




Stange A x 4



Stange B x 3



Stange C x 2



Eckverbinder x 2



Aufhänger x 8



Wassersack x 2




Heringe x 5



Nylonseil x 2 (ca. 8 m)






Leinwand x 1




Aufbewahrungsbeutel x 1


**TEILE FÜR DIE AUFSTELLUNG**



5



Einsatz im Außenbereich



Hinweis: Nicht bei Wind verwenden - dies könnte zu Verletzungen führen oder das Produkt beschädigen.

Füllen Sie den Beutel mit Wasser und bringen Sie ihn in der oben gezeigten Position an. Fügen Sie bei leichtem Wind das Nylonseil, den Hering und den Wassersack hinzu - halten Sie ihn sicher.