























INcqc065\_GL

836-442\_836-442V01




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


# ASSEMBLY INSTRUCTION

A  X1	C  X2	F  X4	I  X1	L  X2	O  X6
B1  X1	D  X1	G  X4	J  X2	M  X4	P  X4
B2  X1	E  X4	H  X1	K  X1	N  X1	Q  X1


1




2



3



4





001-877-644-9366  
customerservice@aosom.com



001-855-537-6088  
customerservice@aosom.ca



0044-800-240-4004  
enquiries@mhstar.co.uk



0049-(0)40-88307530  
service@aosom.de



0033-1-84166106  
contact@aosom.fr



0034-931294512  
atencioncliente@aosom.es



0039-0249471447  
clienti@aosom.it