



A x 1



B x 4




E x 1



C x 1



D x 1




F x 1




G x 1

B x 4





C x 1



01



02



ON/OFF

3 * AA
(Not included)

2 * AA
(Not included)

USE 2 AG13 BATTERIES

(included)

This section provides information about the device's power requirements. It features a pink oval containing an illustration of a battery compartment with an ON/OFF switch. Below this, it specifies that 3 AA batteries are required but not included. To the right, a battery is shown inserted into a holder, with the text '2 * AA (Not included)'. Further right, a diagram shows a hand inserting a battery into a compartment, with the text 'USE 2 AG13 BATTERIES (included)'.

US

If you have any questions, please contact our customer care center.
Our contact details are below:



001-877-644-9366



customerservice@aosom.com

Imported by Aosom LLC
27150 SW Kinsman Rd Wilsonville, OR 97070 USA
MADE IN CHINA

CA

If you have any questions, please contact our customer care center.
Our contact details are below:

Si vous avez la moindre question, veuillez contacter notre centre d'assistance à la clientèle.
Nos coordonnées sont les suivantes:



416-792-6088



customerservice@aosom.ca

Imported by Aosom Canada Inc.
7270 Woodbine Avenue, Unit 307, Markham, Ontario Canada
L3R 4B9
MADE IN CHINA

Importé par Aosom Canada Inc.
7270 Woodbine Avenue, unité 307, Markham, Ontario Canada
L3R 4B9
FABRIQUÉ EN CHINE