


IN230500501V01_UK

342-001_342-002_342-003



Inflatable Bouncer instruction

Maximum weight: 100kgs







Compliance with European and American Standards.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY INSTRUCTION

Congratulations on your new inflatable toy purchase! Please read all instructions carefully before use. Always obey safety precautions as mentioned in these instructions and on the warning label. This item is for home use only, and is not to be used for commercial or rental purpose. Always use common sense safety practices, and monitor children's at all times. If child's actions appear unsafe for the child, cease behaviour immediately.

WARNING:

- CHOKING HAZARD-Small parts.
- Not for children Under 3 years.
- Adult assembly required

CAUTION

- NOT TO BE USED BY ADULTS.
- WARNING! FOR AGE 3-10 YEARS.
- TO BE SET UP BY AN ADULT.
- ADULT SUPERVISION REQUIRED.
- WARNING! PRODUCT IS FOR DOMESTIC USE ONLY.

WARNING

- Failure to follow the specified instructions could result in serious injury.
- USE ONLY UNDER ADULT SUPERVISION.
- Never leave children unattended at any time!
- Observe precautions on product WARNING LABEL at all times.
- (Keep unit at least 2 m) away from heat and open flame, walls and other obstructions. Material will burn or melt when in contact with flame or heat.
- Individuals should not use this product if they have any existing medical conditions such as, Neck, back or joint injuries, heart problems, asthma, bronchitis, infants, pregnant women, circulatory problems or other health concerns. Always consult a physician if you have any concerns.
- Ensure electrical source is safe and stable before operation.
- Keep children and pets away from blower.
- To reduce the risk of fire or electric shock, don't use the blower with any solid state speed control devices.
- Do not insert fingers, toes, etc. into the blower, or it may cause injury.
- Do not bring sharp objects into play area.
- Do not eat in play area. (To prevent choking, children may not enter the product while eating or chewing anything.
- Do not smoke in play area.

- Product should be checked regularly for unsafe conditions such as damaged power cord, Plug, housing, or parts. If such damage is found, the product should not be used until repaired.
- In case of blower malfunction, or starts to deflate, evacuate children from play area immediately check for disconnection of power cord, and to tighten blower vent.
- Do not use in rain/lightning conditions or winds exceeding 40Km/h (25MPH).
- When using slides, never slide head first. Always make sure slide is clear of others before sliding.
- Never stand up on slide platform.
- Do not leave unit inflated or outside when not in use. Exposure to sun or strong weather will destroy fabric.
- Avoid rough play. Rough play is dangerous for children and can damage the unit.
- No Wrestling, running, pushing, is allowed inside the product.
- No climbing or hanging on the walls and netting.
- Check stakes regularly to ensure they remain secured in ground.
- Keep the carry bag away from reach of children.
- This product not suitable for children under 3 years, Small parts may be swallowed,
- Eyeglasses, Shoes, jewellery and any sharp objects that may cause injury must be removed before
- Entering the product, clothing with long cords should not be worn while playing on this product.

SET UP

This product must be set up and supervised by an adult. Use only on grass or soft surfaces. Do not use on concrete, rough surfaces etc. Always make sure the ground is debris-free before setup, and never drag across rough surfaces. Before assembling make sure to place the product on a soft level surface at least 2 meters away from any obstruction, such as garage, fences, over hanging branches, cloth line or electrical wires. Roll product, Connect blower(s) to inlet, and tie. Anchor the blower to the ground using the stakes provided. Do not use the blower near water or in wet conditions. If the blower becomes wet, discontinue use until it is dry. Plug in and start the blower; your unit will inflate within a couple minutes. Leave the blower running the entire time the inflatable is being used. You will hear air "breathing" out of seams and fabric. This is intentional to allow air to escape. Once inflated, anchor the inflatable product to the ground using the stakes provided. Never use the inflatable without anchoring it to the ground.

If the product is water slide, please follow the instruction below.

- Children can drown in very small amounts of water; ADULT SUPERVISION is required at all times.
- Change the water of pool frequently particularly in hot weather, or when noticeably contaminated.

Warning! Never leave your child unattended drowning hazard.





Disassemble Instructions

Ensure that all the players have left play area. Remove any loose articles or debris from play area. Empty any water from water units while still inflated. Allow the unit to continue to run until thoroughly dry. Turn off, and unplug blower. Once product is fully deflated, fold & store in cool, dry area.

Maintenance & Repair

Always keep products clean to protect the seams and surface. Regularly inspect seams and play surface for any necessary repairs. Slight damage caused by nature or man-made factors can be repaired with the repair kit provided. To repair, deflate the product thoroughly, and ensure surface is dry. Cut patches to sizes suitable for repair. Apply glue on both the repair patches, and the damaged surface. For larger punctures and rips, the unit can be repaired using the included patch and strong thread.

Care

In order to get the maximum life out of your inflatable water slide or jumping castle, follow these simple care instructions.

- Make sure the product is free from any objects before packing it
- If the product is a water park, please drain all water from it,

- Allow the water park to run empty, in order for the blower to dry all water from inside materials.
- Never leave your jumping castle outside. Weather will corrode materials.
- Never drag the inflatable across concrete, sharp objects, etc.

Maintenance

- Checks and maintenance of the all parts of this product should be carried out of regular intervals.
- If these checks are not carried out this product could overturn or become a hazard. Whenever practical, the instructions shall also be affixed to the product.
- The inspection and maintenance should be conducted for any damage or leaking of the product.
- If there is a puncture on the surface you can repair with the provided repair kit.
- The Product can be cleaned using mild detergent, please make sure to keep water away from blower at all times.
- Do not store product when wet. Store product in dry conditions when not in use.

If you have any questions, please contact our customer care center. Our contact details are below:



© 0044-800-240-4004



enquiries@mhstar.co.uk

IMPORTER ADDRESS: MH STAR UK LTD Unit 27, Perivale Park, Horsenden lane South Perivale, UB6 7RH MADE IN CHINA

