




INbac003\_US

**84C-243\_84C-243V01**

























READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE









**ASSEMBLY & INSTRUCTION MANUAL**


Warning: .







1. A 3 person assembly is required for this tent.
2. Please take appropriate actions as heavy rain, wind and snow can damage the tent. If necessary please dis-assemble and store for later use.
3. In snowy conditions please do not allow the thickness of the snow to be more than 5cm on the roof, this should be cleared as soon as possible for your safety.



	Description	Sketch	QTY
A1	Roof Tube A1		7 pcs
A2	Roof Tube A2		7 pcs
B1	Roof Tube Curved B1		2 pcs
B2	Roof Tube Curved B2		2 pcs
B3	Connector B3		2 pcs
C1	Lintel C1		2 pcs
C2	Lintel C2		2 pcs
D	Decoration for Post		4 pcs
D4	Top Cover for Post		4 pcs
E	Post E		2 pcs
F	Post F		2 pcs
G	Base Plate		4 pcs
H	Base Plate Cover		4 pcs
I1	Corner Brace I1		2 pcs
I2	Corner Brace I2		2 pcs
J1	Corner Brace J1		2 pcs
J2	Corner Brace J2		2 pcs
L	Connector L		8 pcs





	Description	Sketch	QTY
M	Weight Bar M		2 pcs
N	Weight Bar N		2 pcs
O	Guide Tube		4 pcs
P	Shade Fabric		1 pc


	Description	Sketch	QTY
AA	Bolt M6*15		5 pcs
BB	Bolt M6		7 pcs
CC	Bolt M6*15		1 pc
DD	Bolt M6*45		2 pcs
EE	Bolt M6*70		1 pcs
FF	Anchor FF $\Phi 6 \times 230$		0
Z1	Wrench M6		0
Z2	Anchor Z2 M6		0







	E x 2pcs		G x 4pcs
	F x 2pcs		BB x 8pcs
	H x 4pcs		AA x 8pcs




	<p>D x 4pcs</p>		<p>BB x 12pcs</p>
	<p>D4 x 4pcs</p>		<p>AA x 12pcs</p>









 C2 x 2pcs	 BB x 4pcs
 C1 x 2pcs	 AA x 4pcs


















	<p>B1 x 2pcs</p>	
	<p>B2 x 2pcs</p>	 <p>BB x 8pcs</p>
	<p>B3 x 2pcs</p>	 <p>AA x 8pcs</p>








	 BB x 16pcs
 DD x 8pcs	 AA x 8pcs







	J1 x 2pcs		I1 x 2pcs
	J2 x 2pcs		BB x 32pcs
	I2 x 2pcs		AA x 32pcs









 A2 x 7pcs	 BB x 14pcs
 A1 x 7pcs	 CC x 14pcs







	<p>A1、 A2 x 5pcs</p>
	<p>DD x 10pcs</p>
	<p>BB x 10pcs</p>






	M x 2pcs		
	N x 2pcs		BB x 4pcs
	P x 1pc		CC x 4pcs





	O x 4pcs
 L x 8pcs	 EE x8pcs



	A1、A2 x 2pcs
	DD x 4pcs
	BB x 4pcs





FF x 8pcs

US



001-877-644-9366  
customerservice@aosom.com

CA



001-855-537-6088  
customerservice@aosom.ca

UK



0044-800-240-4004  
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530  
service@aosom.de

FR



0033-1-84166106  
contact@aosom.fr

ES



0034-931294512  
atencioncliente@aosom.es

IT



0039-0249471447  
clienti@aosom.it