

1. Parts

| No. | Parts | Qty. |
|-----|--|------|
| A | Table Top | 1 |
| B | Leg Ring Support | 1 |
| C | Side Panel | 3 |
| D | Door | 1 |
| E. | Burner Support | 1 |
| F. | Burner | 1 |
| G. | Burner Cover | 1 |
| H. | Bolt (8x40mm) | 4 |
| I. | Washer, Spring washer & nut (8mm) | 4 |
| J. | Bolt (6*35), Washer, Spring washer & nut | 18 |
| L | Latch plate (6*45), | 1 |
| N | Wrench | 1 |

2. Assembly Instruction:

Step 1. Fix The Side Panels(C) onto the the Legs Ring Support(B) with Bolt (6*35), Washer, Spring washer & nut (J) . Be careful the upper side and the under side. Please refer to Fig.1

Step 2. Fix the burner support on the panels with Bolt (6*35), Washer, Spring washer & nut (J) . Please refer to Fig.1

Step 3. Fix the Upper side of the door(D) on the Burner Support (E) and fix the underside of the Door (D) on the Legs Ring(B) with The Latch Plate(L). Please refer to Fig.1 and Fig.3




Fig.1

Step 4. Adjust the Burner Support(E) and Tighten the Screws. Please refer to Fig.1

Step 5. Fix the Burner(F) on the Burner Support(E),make sure the switch of the burner is aligned with the door(D). Please refer to Fig.2 and Fig3.

Step 6. Put the Tabletop up side down,fix the TableTop(A) on the unit with Washer, Spring washer & nut (8mm) (I) Please refer to Fig.4

Step 7. Put the burner cover(G)on the Burner. Please refer to Fig.5 and Fig 6



Fig.2



Fig.3



Fig.4



Fig.5



Fig.6