



















Part#	Figure	Qty
A1		2
A2		2
B1		6
B2		2
B		4
C1		1
C2		1
C		4
D1		1
D2		1
D		4
E		4
F		4
G		2
H1	 M 6 x12	8
H2	 M 6 x16	22


Part#	Figure	Qty
H3	 M 6 x32	18
H4	 M 6 x32	30+1
I		2
J1		2
J2		4
K		1
L		4
M		1
N		1
V		1
W		1
X		1
Y		16
Z		1




④




⑤



⑥



⑦



Note: This product must be securely fixed to the ground surface, to prevent damage in big windy days.  
And it is recommended to put down the Extend tent during big windy days.

Notice: Ce produit doit être solidement fixé au surface du sol, pour prévenir des dommages éventuels pendant les jours de grands vents. Et il est également recommandé de poser la tente d'extension pendant les jours de grands vents.

Hinweis: Dieses Produkt muss sicher auf dem Boden befestigt werden, um Schäden bei windigem Wetter zu vermeiden. Zudem empfehlen wir Ihnen, den Pavillon bei windigem Wetter abzubauen.