





INbkc001_GL

845-457




READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE


ASSEMBLY & INSTRUCTION MANUAL



① x 2




⑦ x 4




② x 6




A x 12




③ x 2




B x 48




④ x 2




C x 6




⑤ x 2




D x 8



⑥ x 2





E x 8




F x 8


A x12




B x 16




C x 6




B x32




D x 8



F x 8



E x 8



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it