



INbma092V01_IT

845-730



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY & INSTRUCTION MANUAL

Higen Upgraded Extra Strong

Expandable Garden Hose

THE COMPLETE GUIDE TO GARDEN HOSE FITTINGS

The hose is a modern hose that automatically extends up to three times compared to its initial length when the water is in the ON position and automatically shrinks back to its "relaxed" length when the water is in the OFF position. The weight of the hose is rather light. This will allow avoiding dirty work when using heavy bulky ordinary hoses.

PACKAGE CONTENT



INTRODUCTION TO USE

1. Before using your expand hose place the rubber washer firmly inside the female coupling. This will prevent leaking. When using the expand hose for the first time, it is recommended to first fill and extend hose and slightly stretch hose to release tightness in outer folded material covering. Then release water and refill to use normally.
2. Attach the female end of the expand hose to the water source.
3. Attach the supplied ON/OFF valve to the male end of the expand hose.
4. Turn the ON/OFF valve to the OFF position.
5. Turn the water on at the source. Gradually increase the water pressure. The expand hose will automatically expand up to 3 times its original length.
6. When the expand hose is fully expanded turn the ON/OFF valve to the ON position. You can now press the handle of sprinkler, use the expand hose like any ordinary hose.
7. When you are finished using the expand hose, turn the water OFF at the source spigot.
8. Allow the water in the expand hose to drain by turning the ON/OFF valve to the ON position. If you are using a nozzle then open the nozzle. As the water begins drain, the expand hose, it will automatically contract back to its original length.

IMPORTANT: This hose is intended for routine watering

- ◆ Do not run hot water through this hose.
- ◆ Do not leave the water turned ON and the hose under pressure when not in use.
- ◆ Drain your hose in the summer when you are not using it and keep it shaded as much as possible.
- ◆ Protect your hose from harsh winter weather by storing it indoors. Be sure to drain the hose completely before storage as water remaining in the hose can freeze, damaging the hose.

STOP!

**PLEASE READ ALL OF THE IMPORTANT INFORMATION
ON REVERSE SIDE BELOW BEFORE USING YOUR MAGIC HOSE**

INSTRUCTIONS for using your MAGIC HOSE with a SPRINKLER

1. Turn the water on at the source and your MAGIC HOSE will expand to its maximum length. When using the MAGIC HOSE for the first time, it is recommended to first fill and extend hose and slightly stretch hose to release tightness in outer folded material covering. Then release water and refill to use normally.

2. Attach your sprinkler to the joint of hose.

3. Place your sprinkler in the desired place in your yard or garden.

4. Point the sprinkler nozzle away from you and press the handle of sprinkler and walk away.

Your sprinkler will work the same way it works with any ordinary hose.

NOTE: If you are using a sprinkler that is NOT attached to the ground, (such as an oscillating sprinkler), when you turn the water Off, your sprinkler may be dragged a short distance as the MAGIC HOSE contracts back to its original length. This should not harm your MAGIC HOSE or your sprinkler.

WARNING

THE MAGIC HOSE IS NOT INTENDED FOR DRINKING WATER USE

Do NOT drink from this hose. The MAGIC HOSE a tool that is used and stored outdoors and can be exposed to conditions that can be harmful to humans such as:

- Mold & bacteria
- Lawn and Garden chemicals
- Insects
- Stagnant water
- Other harmful substances

WARNING

THE MAGIC HOSE IS NOT A TOY

Do not stretch or expand this hose when it is empty. The MAGIC hose is mended to expand only when the water is turned on. This hose can stretch to up to three times its "relaxed" or original length and if it is stretched with NO water in it and accidentally released, it will quickly snap back and could cause personal injury.

Higen Aggiornato e più forte

Tubo da giardino espandibile

LA GUIDA COMPLETA ALL'ASSEMBLAGGIO DEL TUBI DA GIARDINO

Il tubo è un tubo moderno che si estende automaticamente fino a tre volte rispetto alla sua lunghezza iniziale quando è in posizione ON con acqua e si restringe automaticamente alla sua lunghezza "rilassata" quando è in posizione OFF. Il peso del tubo è molto leggero il che ti consentirà di evitare il lavoro sporco in caso che utilizzassi i tubi normali pesanti e ingombranti.

Contenuto di imballaggio



INTRODUZIONE ALL'USO

1. Prima di usare il tubo di espansione, posizionare saldamente la rondella di gomma all'interno dell'innesto femmina per evitare la perdita di acqua. Quando si utilizza il tubo di espansione per la prima volta, si consiglia di riempire ed estendere il tubo e allungarlo leggermente per rilasciare il rivestimento esterno in materiale piegato, e poi fare entrare l'acqua per utilizzare normalmente.
2. Collegare l'estremità femmina del tubo di espansione alla fonte d'acqua.
3. Collegare la valvola ON/OFF in dotazione all'estremità maschio del tubo di espansione.
4. Ruotare la valvola ON/OFF in posizione OFF.
5. Aprire il rubinetto dalla fonte dell'acqua. Aumentare gradualmente la pressione dell'acqua. Il tubo di espansione si espanderà automaticamente fino a 3 volte la sua lunghezza originale.
6. Quando il tubo di espansione è completamente espanso, ruotare la valvola ON/OFF in posizione ON. Ora puoi premere la maniglia dell'irrigatore, utilizzare il tubo di espansione come un normale tubo.
7. Quando hai finito di usare il tubo di espansione, chiudere l'acqua dal rubinetto della fonte.
8. Lasciare che l'acqua nel tubo di espansione si scarichi ruotando la valvola ON/OFF in posizione ON. Se stai usando un ugello, apri l'ugello. Quando l'acqua inizia a defluire, il tubo di espansione si contrarrà automaticamente alla sua lunghezza originale.

IMPORTANTE: questo tubo e' progettato per l'annaffiamento di routine.

- Non far passare acqua calda attraverso questo tubo.
- Quando non è in uso, non lasciarlo in posizione ON con il tubo in pressione.
- Lasciare defluire il tubo in estate quando non lo utilizzi e lo tieni all'ombra il più possibile.
- Progettare il tuo tubo dalle rigide condizioni invernali conservarlo al chiuso. Assicurarsi di scaricare completamente l'acqua dal tubo prima di conservarlo perché l'acqua rimanente nel tubo può congelarsi e danneggiare eventualmente il tubo.

ATTENZIONE!

SI PREGA DI LEGGERE TUTTE LE INFORMAZIONI IMPORTANTI SUL RETRO SOTTO PRIMA DI UTILIZZARE IL TUBO MAGICO

ISTRUZIONI per utilizzare il TUBO MAGICO con un IRRIGATORE

1. Aprire il rubinetto dell'acqua alla fonte e il tuo Tubo Magico si espanderà fino alla sua lunghezza massima. Quando si utilizza il Tubo Magico per la prima volta, si consiglia di riempire ed estendere il tubo e allungare leggermente il tubo per rilasciare il rivestimento esterno in materiale piegato, e poi fare entrare l'acqua per utilizzare normalmente.
2. Collegare il tuo irrigatore al connettore del tubo.
3. Posizionare il tuo irrigatore nel luogo desiderato nel tuo cortile o giardino.
4. Puntare l'ugello dell'irrigatore lontano da sé e premere la maniglia dell'irrigatore e allontanarsi.

Il tuo irrigatore funzionerà allo stesso modo di un normale tubo flessibile.

NOTA: se si utilizza un irrigatore NON fissato a terra (come un irrigatore oscillante), quando si chiude l'acqua, l'irrigatore potrebbe essere trascinato per una breve distanza mentre il Tubo Magico si contrae alla sua lunghezza originale il che non dovrebbe danneggiare il tuo TUBO MAGICO o il tuo irrigatore.

AVVERTENZA

IL TUBO MAGICO NON È DESTINATO ALL'USO DI ACQUA POTABILE
NON bere da questo tubo. Il TUBO MAGICO è uno strumento che viene utilizzato e messo all'aperto e può essere esposto a condizioni che possono invece essere dannose per l'uomo come:

- Muffe e batteri
- Prodotti chimici per prato e giardino
- Insetti
- Acqua stagnante
- Altre sostanze nocive

AVVERTENZA

IL TUBO MAGICO NON È UN GIOCATTOLO

Non allungare o espandere questo tubo quando è vuoto. Il Tubo Magico si espande solo in posizione On con acqua scorrendo dentro. Questo tubo può allungarsi fino a tre volte la sua lunghezza "rilassata" o originale e se viene allungato senza acqua e rilasciato accidentalmente, si restringe rapidamente e potrebbe causare lesioni personali.