





INbmb060_GL














845-478





READ AND SAVE THIS INSTRUCTION FOR FUTURE USE


ASSEMBLY INSTRUCTION




 <p>A x 2</p>	 <p>A1 x 2</p>	 <p>B x 2</p>
		 <p>C x 2</p>
 <p>D x 1</p>	 <p>E x 1</p>	 <p>F x 1</p>
 <p>G x 1</p>	 <p>H x 1</p>	 <p>I x 1</p>
 <p>① x 1</p> <p>M5*20</p>	 <p>② x 12</p> <p>M5*40</p>	 <p>③ x 1</p>



03




04




① x 1

05



06



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it