























INbmb065_GL

845-396




READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL


 ① x 2	 ⑤ x 1	 ⑨ x 2	 A x 24
 ② x 2	 ⑥ x 2	 ⑩ x 11	 B x 8
 ③ x 1	 ⑦ x 2	 ⑪ x 1	 C x 4 
 ④ x 2	 ⑧ x 2	 ⑫ x 3	 D x 4 
			 E x 44

A x 6




C x 2


B x 8




A x 6




C x 2




A x12



D x 4




E x12




E x32


08



09



Done



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it