



















INbmb068_GL

845-454




READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL


 1 x 1	 5 x 1	 11 x 4
 2 x 1	 6 x 1	 12 x 2
 3 x 1	 7 x 4	 A x 48
 4 x 1	 8 x 4	 B x 8
	 10 x 4	 C x 8
		

A x 12


01




A x12




B x 4




x2




C x 4







C x 4



A x24



Done



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it