




INbmb085_GL

845-638




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


ASSEMBLY & INSTRUCTION MANUAL

PARTS

EP1x02
L403



EP2x02
L600




EK1x04
L403




HARDWARE


S3x32
+2(spare)



L3x32
+2(spare)



01



x2

