





INbme002_GL













845-373



READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL




 A x 1	 D x 1	 G x 1
 B x 1	 E x 1	 G1 x 1
 C x 1	 F x 1	 ① x 22
 C1 x 1	 F1 x 1	 ② x 6
		 ③ x 1


M6*40

M4*30


① x 4




M6*40




① x 4




M6*40




① x 4




M6*40





① x 4




M6*40







① x 6



M6*40



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it