

















INbpc033_GL

84D-184_84D-184V01




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


ASSEMBLY & INSTRUCTION MANUAL

A x 1**B** x 1**C** x 1**D** x 1**G** x 1**I** x 1**J** x 1**K** x 1**L** x 1**P** x 2**Q** x 4**S** x 1**T** x 1**U** x 1

E x 8
M8
+1(spare)




F x 8
Φ8
+1(spare)



H x 1
M8



M x 2
M6



N x 2
Φ6



O x 1
M6



R x 4

