





INbvc027V01_GL

845-686




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


ASSEMBLY & INSTRUCTION MANUAL






PARTS





HARDWARE





① x 4
M4*30









1 x 16
M4*30





2 x 6
M4*40




1 x 1
M4*30





3 x 6
M3*14



3 x 4
M3*14



4 x 1



3

4

