





INbwa024_GL

845-612V01



120MIN



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Tools Recommended

ASSEMBLY & INSTRUCTION MANUAL

PARTS


1 x15




2 x 5




3 x10




4 x 7




5 x14




6 x 7




7 x 2



8 x 2




10 x 4




HARDWARE

H x35
M6*50
+1(spare)




K x35
+1(spare)



A x14
+1(spare)



B x 4




C x 4




D x 1




- 1 x6
- 2 x2
- 5 x3
- 6 x3
- A x3
- H x6
- K x6




- 3 x4
- 5 x4
- 6 x4
- 7 x1
- 8 x1
- 10 x2
- A x4
- H x8
- K x8




- 1 x3
- 2 x1
- 3 x2
- 5 x7
- H x7
- K x7



- 1 x3
- 2 x1
- 3 x2
- 4 x7
- 10 x2
- H x7
- K x7



- 1 x3
- 2 x1
- 3 x2
- 7 x1
- 8 x1
- H x7
- K x7



- B x4
- C x4
- D x1

