





EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

FR_IMPORTANT: A LIRE ATTENTIVEMENT ET À CONSERVER POUR CONSULTATION ULTÉRIEURE.

ES_IMPORTANTE, LEA Y GUARDE PARA FUTURAS REFERENCIAS.

DE_WICHTIG! SORGFÄLTIG LESEN UND FÜR SPÄTER NACHSCHLAGEN AUFBEWAHREN.

IT_IMPORTANTE! CONSERVARE IL PRESENTE MANUALE PER FUTURO RIFERIMENTO E LEGGERLO ATTENTAMENTE.



EN_1. Insert the antlers (See Fig.A) into the head.

2.Insert plug into socket between reindeer and sleigh (See Fig.B).

FR_1. insérer les bois (voir Fig. A) dans la tête.

2. insérez la fiche dans la prise située entre le renne et le traîneau (voir figure B).

Input voltage	220-240V	V
Input AC frequency	50-60Hz	Hz
Output voltage	31	V
Output current	0.193	A
Output power	6W	W
Average active efficiency	68	%
Efficiency at low load (10 %)		%
No-load power consumption	0.3W Max	W