









READ AND SAVE THIS INSTRUCTION FOR FUTURE USE


ASSEMBLY INSTRUCTION



									
A	3pcs	B	3pcs	C	22pcs	D	56pcs	E	55pcs
									
F	55pcs	G	2pcs	H	18pcs	I	2pcs	J	4pcs
									
K	8pcs	L	2pcs	M	2pcs	N	4pcs	O	2pcs
									
P	2pcs	Q	2pcs	R	2pcs	S	2pcs	T	4pcs
									
U	8pcs								


Fx12

01





Fx1
Bx3
Ax3

02




Dx4
Ex6

03




Cx6
Fx8

04




Hx4
Px1
Qx1


05





Hx4
Px1
Qx1







Dx2
Fx2



D x2
E x2
F x4





D x24
E x8
F x8



x2



E x5

10





D x3
E x3



11




D x1
E x5





D x6
E x6





C x6
D x6
F x8




E x4
F x4





D x8
E x8



K x8
J x4
U x8






Cx8
Hx8
Rx2
Sx2




X2



E x8 L x2
F x8 M x2




X2







I x2
N x4



C x2
G x2
H x2
T x4



O x2



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it

Aosom