
























READ AND SAVE THIS INSTRUCTION FOR FUTURE USE


# ASSEMBLY INSTRUCTION

**Attention: Do not tighten the screws until all of them are in right positions**

<p>1</p>  <p>X1</p>	<p>2</p>  <p>X2</p>	<p>3</p>  <p>X2</p>	<p>4</p>  <p>X1</p>	<p>5</p>  <p>X1</p>
<p>6</p>  <p>X2</p>	<p>7</p>  <p>X2</p>	<p>8</p>  <p>X2</p>	<p>9</p>  <p>X2</p>	<p>10</p>  <p>X2</p>
<p>11</p>  <p>X2</p>	<p>12</p>  <p>X4</p>	<p>13</p>  <p>X2</p>	<p>A</p>  <p>M6X10 X20</p>	<p>B</p>  <p>M6X25 X4</p>
<p>C</p>  <p>M6X30 X8</p>	<p>D</p>  <p>M6X35 X12</p>	<p>E</p>  <p>M5X50 X10</p>	<p>F</p>  <p>X4</p>	<p>H</p>  <p>X4</p>
			<p>G</p>  <p>M6X12 X4</p>	




3




E	X10
---	-----

4




A	X16
---	-----


5



B	X4
C	X4




6




D	X12
F	X4

7




8





C X4

9



A X4

10





US



001-877-644-9366  
customerservice@aosom.com

CA



001-855-537-6088  
customerservice@aosom.ca

UK



0044-800-240-4004  
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530  
service@aosom.de

FR



0033-1-84166106  
contact@aosom.fr

ES



0034-931294512  
atencioncliente@aosom.es

IT



0039-0249471447  
clienti@aosom.it