




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


ASSEMBLY & INSTRUCTION MANUAL

PARTS


A x 2




B x 2




C x 1




D x 1



E x 2




F x 4




HARDWARE

G x 4
M8*45



H x 4
M8



I x 8
M8



J x 8
M6*37



K x 8
M6



L x 8
M6



M x 16
M4.8*15



A x 2

B x 2

J x 8



M6*37

K x 8

M6

L x 8

M6



C x 1

D x 1

G x 4



M8*45

H x 4

M8

I x 8

M8





E x 2



M x 16

M4.8*15

03




04




F x 4





F

Done



OPERATION GUIDE





US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it