





INcfb068_GL

838-135




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY & INSTRUCTION MANUAL

PARTS


① x 1




② x 1




③ x 1




④ x 2



⑤ x 1



⑥ x 1




HARDWARE

A x 8




M6X12

B x 3



M6X25

C x 2



M6X40

D x 3




M6

E x 1




2" (M8)


F x 1




G x 1



H x 1






.SCREWS

E 2" (M8) 
    1 PCS 


01



.SCREWS


C M6x40 
 2 PCS

02



.SCREWS

D M6
2 PCS




.SCREWS

A M6X12
8 PCS






B M6X25
3 PCS

F
1 PCS



.SCREWS

D

M6
1 PCS**OR**

Done

US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it