




Avoid direct sunlight.Do not put them in very damp or dry place.


Do not use it for other purposes.


When adjust the backrest, please watch your hands and feet.

Use dilute neutral detergent to clean obvious stain.

Do not rush to the bacrest, this will add more prssure to it, may cuse damage to the item.







Step1
Remove floor chair from packaging.

Step 2

Lay flat on the ground with one hand on seat bottom and pull up backrest which clicks into multiple back support positions. Stop when comfortable position is reached.

Step 3

To fold flat, push back support all the way forward and then it will fold back to flat position.

Note

- 1.Please don't mix up the seat board and backrest, or it will affect the function, even damage to your sofa.
- 2.If you wrongly use the item as picture, it will reduce the service life.

