




INcgb154_GL

839-170




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


ASSEMBLY & INSTRUCTION MANUAL

PARTS

1 x01




2 x01




3 x02




4 x01




5 x01




6 x01




7 x04



A x04
ST 5x40




B x04
M6x30




C x04
M6x8



D x01




E x01



HARDWARE


⑥ x01



① x01

② x01

⑦ x04




③ x02

④ x01

A x04

B x04



⑤ x01

C x04

