

Assembly Instructions

<p>Ax5</p>	<p>Bx1</p>	<p>1</p>	<p>2</p>
<p>Cx1</p>	<p>Dx1</p>	<p>3</p>	<p>4</p>
<p>Ex1</p>	<p>Fx1</p>	<p>5</p>	<p>6</p>
<p>Gx1</p>	<p>Hx1</p>		
<p>Ix1</p>	<p>Jx1</p>		
<p>Kx4</p>	<p>Lx1</p>		
<p>Mx1</p>	<p>Nx2</p>		