




INcmc055_GL

850-153




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


ASSEMBLY & INSTRUCTION MANUAL

PARTS


A x01




B x01



C x01




D x01



E x01




F x01




H x02



G x01




I x01




HARDWARE

a x10
+1(spare)




b x01



A x01



B x01




E x01



H x02



a x05




C x01




D x01



F x01



G x01



I x01



a x05

