



















IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY & INSTRUCTION MANUAL

PARTS




HARDWARE



B x 1


01

I x 6




J x 6

02




A x 1

03




K x 6

04



A x 1

05




M x 2

06

N x 4

Q x 4


R x 4




H x 1

O x 2

P x 2




L x 6



D x 3

09




C x 1

E x 1

F x 2

G x 1

Done



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it