
























READ AND SAVE THIS INSTRUCTION FOR FUTURE USE


ASSEMBLY INSTRUCTION

 1x1	 9x1	 17x2
 2x1	 10x2	 18x2
 3x1	 11x2	 19x2
 4x1	 12x2	 20x2
 5x1	 13x4	 21x2
 6x1	 14x4	 22x2
 7x1	 15x1	
 8x1	 16x1	


A x30




H x6




B x30




I x 8




C x12




J x 8




D x24




E x28



F x 8





G x 8




A x 3
F x 3
E x 6

01





2




A x 3
F x 3
E x 6

02






3






F x 2
E x 4

03




5



5


B x 3
C x 1

04




B x 3
C x 1

05




D x 2

06




A x 6

07




B x 6
C x 6

08




D x 4
C x 4

09




I x 4

10




G x 4

11



G x 4
I x 4



12



D x 8
A x 8

B x 8
E x 4
H x 2



13



x2

A x 10
B x 10
D x 10


14



x2

H x 4
E x 8


15



x2


J x 8

16



x2

Done



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it