




















READ AND SAVE THIS INSTRUCTION FOR FUTURE USE


ASSEMBLY INSTRUCTION

	1 x 1	9 x 4	
	2 x 1	10 x 1	
	3 x 1	11 x 2	
	4 x 1	12 x 3	
	5 x 2	13 x 3	
	6 x 1	14 x 3	
	7 x 1	15 x 3	
	8 x 2		


Ax24



Hx 6




Bx24



Ix 2




Cx12



Jx 2




Dx12




Kx 4




Ex12




Lx 2




Fx12




Mx 2



Gx 4





Nx 6





A	x 4
D	x 6
H	x 3

01




A	x 4
D	x 6
H	x 3

02




B	x 4
C	x 2

03




B	x 4
C	x 2

04




C	x 4
G	x 4

05




E	x12
---	-----


06



07




08




09

A	x 4
B	x 4
C	x 4




A	x 4
B	x 4
F	x 4

10



A	x 8
B	x 8
F	x 8


11



x2


N	x 6
---	-----

12




I	x 2
J	x 2
K	x 2

13




L	x 2
M	x 2
K	x 2

14



15



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it