




Tools Recommended

# ASSEMBLY INSTRUCTION


**①**




**②**



**③**




**④**




**x2**

**⑤**



**⑥**




**x8**

**x8**

**A x64**



**C x16**




**E x 2**

**B x64**



**D x64**



01



① x1

Ⓐ x8

Ⓒ x2

02



② x1

Ⓐ x8



Ⓒ x2

03

③ x2



Ⓐ x32

Ⓒ x8



x2




04



④ x1


Ⓐ x16

Ⓒ x4




|   |    |
|---|----|
| ② | x1 |
| ⑤ | x2 |
| ⑥ | x2 |
| Ⓑ | x8 |




02 STEP






|   |    |
|---|----|
| ③ | x1 |
| Ⓑ | x8 |



|   |    |
|---|----|
| 5 | x2 |
| 6 | x2 |
| B | x8 |




|   |    |
|---|----|
| 4 | x1 |
| B | x8 |




x8

|   |    |
|---|----|
| 5 | x2 |
| 6 | x2 |
| B | x8 |




x8


03  
STEP

|   |    |
|---|----|
| 3 | x1 |
| B | x8 |


11




|   |    |
|---|----|
| ⑤ | x2 |
| ⑥ | x2 |
| Ⓑ | x8 |





12





|   |    |
|---|----|
| ① | x1 |
| Ⓑ | x8 |






x2



|   |    |
|---|----|
| E | x2 |
|---|----|

|   |     |
|---|-----|
| D | x64 |
|---|-----|



US



001-877-644-9366  
customerservice@aosom.com

CA



001-855-537-6088  
customerservice@aosom.ca

UK



0044-800-240-4004  
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530  
service@aosom.de

FR



0033-1-84166106  
contact@aosom.fr

ES



0034-931294512  
atencioncliente@aosom.es

IT



0039-0249471447  
clienti@aosom.it