














READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL






<p>A x64</p> 	<p>B x64</p> 	<p>C x8</p> 	<p>D x2</p> 	<p>E x2</p> 	
<p>F x2</p> 	<p>G x66</p> 	<p>H x2</p> 	<p>I x2</p> 	<p>J x2</p> 	<p>K x4</p> 


A x24

B x24


C x 4



x2




x2



A x16


B x16



E x 2

F x 2

05



D x 2



H x 2

I x 2

J x 2

K x 4

06



Done

US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it