










































Please read these instructions and warranty information carefully before use and keep them properly for future reference.


Assembling Instruction

Attention: Do not tighten them until all of them are in right positions

1  x1	2  x1	3  x1	4  x1	5  x1
6  x1	7  x1	8  x1	9  x1	10  x1
11  x1	12  x1	13  x1	14  x1	15  x1
16  x1	17  x1	18  x1	19  x2	20  x2
A  x16	B  x16	C  M4X35 x12	D  M5X50 x6	E  M4X14 x8
H  M6X40 x4	I  M6X12 x4	J  M4X20 x2	K  M4 x1	L  M6X35 x6
M  x1	N  x1	O  M4X15 x1		
				 




7




A	x6
B	x6

8




C	x4
---	----

9




J	x2
N	x1

10




11




A	x2
B	x2

12




E	x4
M	x1

13




16




G x6

14




H x4

15



F	x4
K	x1
O	x1



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it