







READ AND SAVE THIS INSTRUCTION FOR FUTURE USE

ASSEMBLY INSTRUCTION







$A*2+I*2$




01




$A*4$




02




A*4







A*4







A*2





I*6





$A*4+B*4$ 

$A*4+B*4+I*4$

 $C*4+F*24$


$D*18+E*18$




$D*2+H*2$




G*2

15



16



Done

US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it