























READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL




 <p>A x24</p>	 <p>G x 2</p>	 <p>N x 4</p>
 <p>B x 8</p>	 <p>H x 2</p>	 <p>O x 8</p>
 <p>C x46</p>	 <p>I x 2</p>	 <p>P x 1</p>
 <p>D x16</p>	 <p>J x 2</p>	 <p>Q x 4</p>
 <p>E x10</p>	 <p>K x 8</p>	 <p>R x 4</p>
 <p>F x16</p>	 <p>L x24</p>	 <p>S x12</p>
 <p>M x 4</p>	 <p>T x 2</p>	

M25



M15

M20

E x 2




A x 2




A x 3


B x 3




A x 9

B x 3





F x 6




A x 2


B x 2

C x 2


H x 2




F x 6




F x 4



F x 4




R x 4





O x 8

P x 1



Cx12




Sx12








Cx16


Ix2

Jx2






adjust up and down



A x 8



E x 8

G x 2



x2

L x 24







Cx16




Dx16


Mx4

Qx4




Nx4





T x 2



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it