





















INcra083V01_GL

831-391




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


ASSEMBLY & INSTRUCTION MANUAL

A	 x1	B	 x1		
C	 x2	D	 x1		
E	 x1	F	 x1		
G	 x4	H	 x4  x16		
I	 x1	J	 x1	K	 x8 (6x40)
L	 x2	M	 3.5x14  3.5x40  3.5x40 		


Step 1




Step 2




Step 3



Step 4



Step 5



Step 6

