



















READ AND SAVE THIS INSTRUCTION FOR FUTURE USE



ASSEMBLY & INSTRUCTION MANUAL

A	 x1	B	 x1
C	 x2	D	 x1
E	 x1	F	 x1
G	 x4	H	 x4  x16
I	 x1	J	 x1
L	 x2	K	 x8 (6x40)
M	 3.5x14		 3.5x40  


Step 1




Step 2 Step 3




Step 4



Step 5



Step 6



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it