





831-263




ASSEMBLY INSTRUCTIONS




HARDWARE

A	 15mm	 M6X90mm	16
B			16
C			02
D	 8mm	 Ø 4.5X35mm	06
E	 8mm	 Ø 4.5X25mm	28
F			22
G			02
H			04
I			04
J			02

01




F




22

02




A	 M6X90MM	04
B		04
F	 Ø8x30mm	04

03




A	 M6X90MM	04
B		04
F	 Ø8x30mm	16

04





A	 M6X90MM	04
B		04
F	 Ø8x30mm	02


05




A	 M6X90mm	04
B		04
F	 Ø8x30mm	02


06



C		02
D	 8mm Ø4.5x35mm	06
H		04
I		04

07



E	 8mm Ø4.5x25mm	28
---	---	----

US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it