


831-232



Please read these instructions and warranty information carefully before use and keep them properly for future reference.

OPERATING INSTRUCTIONS

## **Part List**

(A)x1pc	Bx2pcs	©x1pc			
①x1pc	Ex2pcs	F)x2pcs			
		_			
©x1pc	H)x2pcs	①x2pcs			
(a) X 1 po	(1) x2p03	1) 12 pc3			
>					
		324mm			
1)x14pcs	(2)x14pcs				
	(2)X14pcs	3x20pcs			
		8*30			
(4)x4pcs	5)x4pcs	6 x4pcs			
		<b>Ø</b> 8x60			
<b>V</b>					
(7)x2pc	(8)x4pcs	9x4pcs			
	<b>★</b>	<b>\$</b>			
	44.40				
	<b>\$\phi 4 x 4 0</b>	<b>Ø</b> 4x16			
(10)x4pcs	(11)x6pcs	(12)x6pcs			
		<b>®</b> <u>→</u> ************************************			
	46.00	44.25			
Ø6x40	Ø6x20	<b>Ø</b> 4x25			
(12) v1no		1			
(13) x1pc	A				
			<u>,                                      </u>		

## **Assembly Instructions**

