





























READ AND SAVE THIS INSTRUCTION FOR FUTURE USE

ASSEMBLY INSTRUCTION

Attention: Do not tighten the screws until all of them are in right positions

<p>1</p>  <p>X1</p>	<p>2</p>  <p>X1</p>	<p>3</p>  <p>X1</p>	<p>4</p>  <p>X1</p>	<p>5</p>  <p>X1</p>
<p>6</p>  <p>X2</p>	<p>7</p>  <p>X2</p>	<p>8</p>  <p>X2</p>	<p>9</p>  <p>X2</p>	<p>10</p>  <p>X3</p>
<p>11</p>  <p>X1</p>	<p>12</p>  <p>X1</p>	<p>13</p>  <p>X1</p>	<p>14</p>  <p>X1</p>	<p>15</p>  <p>X2</p> <p>16</p>  <p>X2</p>
<p>A</p>  <p>M6X40 X16</p>	<p>B</p>  <p>M15X11 X16</p>	<p>C</p>  <p>M6X35 X4</p>	<p>D</p>  <p>M6X20 X4</p>	<p>F</p>  <p>M4X14 X30</p>
<p>G</p>  <p>M5X50 X2</p>	<p>H</p>  <p>M4X40 X12</p>	<p>J</p>  <p>X3</p>	<p>K</p>  <p>X3</p>	
				


1



X2

H	X8
---	----


2



X2

A	X4
B	X4
F	X4
K	X2


3



X2


F	X8
J	X2

5




A	X4
B	X4
F	X2
K	X1

4




H	X4
---	----


6



F	X4
J	X1




7




A	X4
B	X4

8




9




A	X4
B	X4

10




F	X12
J	X3

11




C	X4
---	----

12





D	X4
---	----

13



G	X2
---	----

14



US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it