





















# ASSEMBLY INSTRUCTION

 <b>A x 4</b>	 <b>E x 1</b>	 <b>I x 1</b>
 <b>B x 2</b>	 <b>F x 1</b>	
 <b>C x 2</b>	 <b>G x 2</b>	
 <b>D x 1</b>	 <b>H x 1</b>	 <b>J x 4</b>

**TOOLS RECOMMENDED**



US



001-877-644-9366  
customerservice@aosom.com

CA



001-855-537-6088  
customerservice@aosom.ca

UK



0044-800-240-4004  
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530  
service@aosom.de

FR



0033-1-84166106  
contact@aosom.fr

ES



0034-931294512  
atencioncliente@aosom.es

IT



0039-0249471447  
clienti@aosom.it