























READ AND SAVE THIS INSTRUCTION FOR FUTURE USE



ASSEMBLY INSTRUCTION

	A x 1		B x 1		C x 2		D x 1		E x 1
	1 x 3		2 x 7		3 x 10		4 x 3		5 x 13
	6 x 1		7 x 4		8 x 1		9 x 4		









US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it