




D51-034



Please read these instructions and warranty information carefully before use and keep them properly for future reference.

OPERATING INSTRUCTIONS

Part List

A 
M6X55
4+1

B 
M3. 5X45
16+1


C 
M3. 5X35
8+1

D 
M3. 0X12
18+1


 2 PCS

 1 PC

 2 PCS




E



F




G




H



I



L



M




N



O




P



Q




R




S


Assembly Instructions




STEP-01



STEP-02




STEP-03




STEP-04


Assembly Instructions




STEP-05




STEP-06




STEP-07



STEP-08



STEP-09



STEP-10