



























Please read these instructions and warranty information carefully before use and keep them properly for future reference.

Assembly Instructions

part list

	 A H41CM 2 PCS	 B H40CM 7 PCS	 C H34CM 3 PCS	 D H20CM 2 PCS	 E H25CM 5 PCS
 1 PCS	 1 PCS	 1 PCS	 1 PCS	 1 PCS	 1 PCS
 1 PCS	 2 PCS	 1 PCS	 2 PCS	 1 PCS	 2 PCS

J		M8*45 16 PCS
K		M8*80 9 PCS
L		M8*60 1 PCS
		SPANNER 1 PCS



step 1

step 2

step 3