




860-060



Parts list



E₁
1PC



E₂
4PCS



E₃
1PC



E₄
4PCS




E₅
4PCS




E₆
1PC

Installation Steps

Step 1



Step 2



Step 3



Parts list



C₁
1PC



C₂
3PCS



C₃
4PCS



C₄
1PC



C₅
1PC



C₆
4PCS




C₇
13PCS




C₈
M6*35
9PCS

Installation Steps

Step 1



Step 2



Step 3



Parts list



D₁
1 PC



D₂
4 PCS



D₃
4 PCS




D₄
4 PCS



D₅
1 PC

Installation Steps

Step 1



Step 2



Parts list



A1
1PC



A2
1PC



A3
4PCS



A4
1PC



A5
1PC



A6
4PCS




A7
7PCS




A8
M6*35
3PCS

Installation Steps

Step1



Step2



Step3



Parts list



B1
1PC



B2
2PCS



B3
4PCS



B4
1PC



B5
1PC



B6
4PCS




B7
10PCS




B8
M6*35
6PCS

Installation Steps

Step1



Step2



Step3

