

















































Safety:the product should be assembled by adult,not suitable for children under three years.
Sicherheit:dieses produkt sollte von erwachsenen, nicht geeignet für kinder unter drei jahren zusammengebaut werden.
Sécurité :ce produit doit etre monté par un adulte, ne convient pas aux enfants de moins de 3 ans.
Seguridad:el producto debe ser montado por un adulto responsable. No apto para niños menores de 3 años de edad.
Sicurezza:il prodotto deve essere assemblato da un adulto, non è adatto a bambini di età inferiore ai 3 anni.




READ AND SAVE THESE INSTRUCTIONS FOR FUTURE USE


ASSEMBLY INSTRUCTION

						
1: 2PCS	2: 2PCS	3: 2PCS	4: 2PCS	5: 2PCS		
						
6: 1PC	7: 1PC	8: 1PC	9: 1PC	10: 1PC		
						
11: 1PC	12: 1PC	13: 1PC	14: 1PC	15: 1PC	16: 1PC	
						
17: 1PC		18: 1PC		19: 1PC	20: 1PC	
						
21: 1PC	22: 1PC	23: 1PC				
24: 1PC						
27: 1PC		28: 1PC				
						
29: 1PC	30: 1PC	31: 1PC	32: 1PC		33: 1PC	34: 1PC
						
35: 1PC		36: 1PC		37: 1PC		
 4X40mm A: 33PCS	 4X12mm B: 10PCS	 3X8mm C: 24PCS	 3X18mm D: 2PCS	 E: 2PCS		
 5X30mm F: 32PCS	 G: 4PCS	 H: 5PCS	 4X30mm I: 12PCS	 J: 1PC	 K: 1PC	


01




02




03




04




05




06




07




08




09




10




11




12




13




14




15




16




17




18




19




20




21




22




23




24




25




26




27




28




29




30




31




32




33




34




35




36




37



38



39



Done

US



001-877-644-9366
customerservice@aosom.com

CA



001-855-537-6088
customerservice@aosom.ca

UK



0044-800-240-4004
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530
service@aosom.de

FR



0033-1-84166106
contact@aosom.fr

ES



0034-931294512
atencioncliente@aosom.es

IT



0039-0249471447
clienti@aosom.it