


**Safety:**the product should be assembled by adult,not suitable for children under three years.

**Sicherheit:**dieses produkt sollte von erwachsenen, nicht geeignet für kinder unter drei jahren zusammengebaut werden.

**Sécurité :**ce produit doit etre monté par un adulte, ne convient pas aux enfants de moins de 3 ans.

**Seguridad:**el producto debe ser montado por un adulto responsable. No apto para niños menores de 3 años de edad.

**Sicurezza:**il prodotto deve essere assemblato da un adulto, non è adatto a bambini di età inferiore ai 3 anni.




**READ AND SAVE THESE INSTRUCTIONS FOR FUTURE USE**

**ASSEMBLY INSTRUCTION**




Bx4

01




Ax2

02




Ax1  
Fx1

03



Ax2  
Fx2



04



05

Fx2

06





Ax1  
Fx4

07

Dx6  
Fx2  
Jx3

08





Ax1  
Fx5

09

Ax4  
Cx6  
Lx2  
Mx1

10





Ax2  
Fx1


11

Ax2  
Fx2


12




**13** Ax2  
Fx1




**14**



Ax2  
Fx2




**15** Dx2  
Ex4  
Fx6  
Ix1  
Ox1  
Px3  
Qx3




**16**

Ax6  
Fx5



**17**





**18**

Ax4  
Fx6

19



Dx4  
Ex24  
Gx2  
Hx4  
Kx2

20



Nx1

21



**Done**

US



001-877-644-9366  
customerservice@aosom.com

CA



001-855-537-6088  
customerservice@aosom.ca

UK



0044-800-240-4004  
enquiries@mhstar.co.uk

DE



0049-(0)40-88307530  
service@aosom.de

FR



0033-1-84166106  
contact@aosom.fr

ES



0034-931294512  
atencioncliente@aosom.es

IT



0039-0249471447  
clienti@aosom.it